

Części niezbędne do złożenia i wykorzystania zawieszki P-B-Z




Elementy niezbędne przy czynnościach montażowych:


- klucz ampulowy
- wiertarka
- kombinerki
- klucze płaskie

UWAGA! Lista produktów, z którymi współpracują wybrane akcesoria dostępna jest na stronie


1. Wywierć otwór o średnicy 10 mm w blacie. Będzie dochodził do niego od spodu przewód z jednym biegunem prądu.




2. UWAGA! Jeżeli blat jest grubszy niż 2 cm, należy sfrezować go od dołu tak, by grubość w miejscu montażu wynosiła maks. 2 cm. Zalecana szerokość frezu to 5 cm - pozwoli to na użycie kluczy płaskich w dalszej części montażu.




3. Podłącz do przewodu łącznik prądowy (H). i nałóż go na śrubę (I). Następnie nałóż podkładkę koronkową (G), nakrętki dolną (F) i górną (E), podkładkę dystansową (D) i podkładkę dolną (C). Gwint wprowadź do otworu.




4. Na górną część gwintu nałóż kolejno podkładkę górną (B) oraz głowicę (A).




5. Dokręć głowicę oraz nakretkę górną tak by zablokować całość w blacie. Dokręć nakrętkę dolną tak by łacznik prądowy i podkładka koronkowa były ciasno ściśnięte. Zaleca się użycie dwóch kluczy płaskich.




6. Zamontuj pręt od oprawy w głowicy. Zablokuj go dokręcając docisk głowicy kluczem imbusowym.





Parts needed for assembly and use of the P-B-Z fastener:




Tools needed when mounting:


- allen key
- drill
- pliers
- flat wrench

NOTE! A list of products corresponding with the selected accessories is available


1. Drill a 10 mm in diameter hole in the countertop. There will be a single pole power wire run under the countertop to this hole.




2. ATTENTION! If the countertop is thicker than 2cm, it needs to be milled from the bottom so that the thickness at the mounting spot will not exceed 2cm . Recommended width of the cutter is 5cm – it will allow to use flat keys in the next phase of the mounting process.




3. Attach the wire to the electrical connector (H) and out it on the bolt (I), then add the locking washer (G), bottom and top nuts (F, E), distance isolating base (D) and bottom isolating base (C). Insert the thread into the whole.



4. On the top part of the thread insert in the following order: top isolating base (B) and head (A).



5. Screw in the head to secure the fastener to the countertop. Tighten the bottom nut so that electrical connector and locking washer are tightended. It is recommended to use two flat wrenches.



6. Insert the rod from the fixture into the head. Block the rod by tightening the allen screw inside the head with the use of allen key.

