



Części niezbędne do złożenia i wykorzystania zawieszki PUSZ-PRET-ZM

Nakrętka z podkładką (H) 


Nakrętka górna (G) 

Podkładka koronkowa (F) 

Łącznik prądowy (E) 

Nakrętka dolna (D) 

Podkładka mała (C) 

Puszka z tuleją (B) 


Gwintowany korek (A) 

Elementy niezbędne przy czynnościach montażowych:


- klucz ampulowy
- wiertarka
- kombinerki

UWAGA! Lista produktów, z którymi współpracują wybrane akcesoria dostępna jest na stronie


1. Wywierć w grzbiecie profilu otwory o średnicy od 4mm do 8mm. Po jednym otworze na zawieszkę.




2. Wklej taśmy LED do profilu. Wsuń gwintowany korek (A) w zamki małe profilu i ustaw go nad nawierconym otworem. Wyprowadź krótki kawałek przewodu (ok. 5-6cm) od jednego bieguna prądu z jednej taśmy LED.




3. Przełóż przewód przez podkładkę małą (C) i nałóż na całość puszkę (B). Dokręć puszkę na gwincie by zablokować ruch zawieszki.



4. Załóż łącznik prądowy (E) na końcówkę przewodu.




5. Zegnij łącznik prądowy (E) tak by wszedł do wnetrza puszki (B). Przełóż nagwintowany pręt przez łącznik i zabezpiecz go nakrętkami (D, G) i podkładką koronkową (F).




6. Nałóż nakrętkę (H) od górnej części pręta.




7. Wsuń całość do puszki i dokręć nakrętkę.



8. Podwieś oprawę na wybranym systemie mocowania.





Parts needed to mount the PUSZ-PRET-ZM fastener

Nut with washer (H)

Top nut (G)

Locking washer (F)

Power connector (E)

Bottom nut (D)

Small washer (C)

Sleeve (B)


Threaded plug (A)

Tools needed for mounting:

- Allen wrench
- drill
- pliers


NOTE! A list of products corresponding with the selected accessories is available at www.klusdesign.eu

1. Drill holes with a diameter of 4mm to 8mm in the back of the extrusion. One hole per fastener.




ø 4-8mm


2. Mount LED strips in the extrusion. Insert the threaded plug (A) into the small locks of the profile and place it over the drilled hole. Run a short cable (approx. 5-6cm) from one pole of a LED strip.




3. Run the cable through the small washer (C) and put the sleeve (B) on the entire assembly. Tighten the sleeve on the arm with thread to stop the fastener from moving.



4. Attach the power connector (E) to the cable end.




5. Bend the power connector (E) so that it fits into the sleeve (B). Put an arm with thread through the connector and secure it with nuts (D, G) and a locking washer (F).



6. Pull the nut (H) on from the top side of the arm.



7. Insert the entire assembly into the sleeve and tighten the nut.



8. Suspend the lighting fixture using a selected suspension system.

