


Części niezbędne do skonstruowania oprawy na bazie profilu KOPRO



Profil (A) | Zaślepka (B) | Osłona (C) | Taśma LED (D) | Sprężyna (E)


Elementy niezbędne przy czynnościach montażowych:

- wiertarka
- wkrętarka / śrubokręt


UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.

WAŻNE: Instrukcja przedstawia podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie


1. Wywierć otwory na powierzchni montażowej (min. Ø 10 mm) na zamocowanie profilu.




2. Wywierć otwory montażowe w profilu.




3. Wklej taśmę LED (D),




4. Podłączyć zasilanie, następnie umieścic profil za pomocą sprężyn w wcześniej przygotowanych otworach.



5. Załóż osłonkę (C) oraz zaślepkę (B).





Parts needed to mount the KOPRO extrusion



Extrusion (A) | End cap (B) | Cover (C) | LED strip (D) | Spring (E)


Tools needed for mounting:

- drill
- screwdriver


NOTE! All LED strips must be connected to a 12 V or 24 V power supply.

IMPORTANT: The manual presents the simplest mounting procedure.
More mounting procedures and related accessories can be found at


1. Drill holes in the mounting surface (min. ø 10 mm) to mount the extrusion.




2. Drill holes in the extrusion for mounting.



3. Mount the LED strip (D).



4. Connect power, then mount the extrusion in the drilled holes using springs.



5. Insert the cover (C) and the end caps (B).

