


Części niezbędne do skonstruowania oprawy na bazie profilu KRAV-56



Profil (B)



Zaślepka (C)




Taśma LED (E)


UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.

WAŻNE: Instrukcja przedstawia podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie


1. Wklej taśmę LED (B) do górnej części profilu (A) i wyprowadź przewód zasilający .




3. Odtłuść szybę i przyklej górną część profilu (A).




4. Przyklej dolną część profilu (A).




5. Załóż zaślepki (B).



6. Podłącz zasilanie.





Parts needed to mount the KRAV-56 extrusion



Extrusion (A and B)



End cap (C)




LED strip (E)


WARNING! All LED strips should be connected to a 12 V or 24 V power supply.

IMPORTANT: The mounting instructions present the basic form of assembly.
More methods and related accessories can be found at


1. Mount the LED strip (E) in the upper part of the extrusion (B) and lead out the power cable.




3. Degrease the glass and attach the upper part of the extrusion (B).



4. Attach the lower part of the extrusion (B).



5. Insert the end caps (C).



6. Connect power.

