


Części niezbędne do skonstruowania oprawy na bazie profilu PDS-O



Mocownik (A)



Profil (B)



Taśma LED (C)



Osłona (D)



Zaślepka (E)


Elementy niezbędne przy czynnościach montażowych:

- wiertarka
- wkrętarka / śrubokręt


UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.

WAŻNE: Instrukcja przedstawia podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie


1. Wyprowadź przewód zasilający. Przykręć mocownik (A) do powierzchni.




2. Zainstaluj taśmę LED (C) w profilu (B), załóż osłonę (D) i zaślepki (E).



3. Podłącz zasilanie do paska LED i umieść profil (B) w mocownikach (A).





Parts needed to mount the PDS-O extrusion



Mounting bracket (A



Extrusion (B)



LED strip (C)



Cover (D)



End cap (E)


Tools needed for mounting:

- drill
- screwdriver


WARNING! All LED strips should be connected to a 12 V or 24 V power supply.

IMPORTANT: The mounting instructions present the basic form of assembly.
More methods and related accessories can be found

1. Feed the power cable. Attach the mounting bracket (A) to the surface with screws.



2. Install the LED strip (C) in the extrusion (B), insert the cover (D) and the end caps (E).



3. Connect power to the LED strip and mount the extrusion (B) in the mounting brackets (A).

