



Części niezbędne do skonstruowania oprawy na bazie profilu KOZUS-50.



Profil (A) | Zaślepka (B) | Osłona (C) | Taśma LED (D) | Wkładka ochronna (E)

Elementy niezbędne przy czynnościach montażowych:


- klej montażowy

WKŁADKA OCHRONNA TECH-50 zapewnia zachowanie szerokości gniazda profilu dla wpinanej osłony (jej stosowanie jest KONIECZNE podczas czynności montażowych i wykończeniowych).


UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.

WAŻNE: Instrukcja przedstawia podstawową formę montażu.
Więcej metod i powiązanych akcesoriów znajdziesz na stronie


1. Wywierć otwór na przewody w profilu.




2. Umieść taśmę LED (D) w profilu, wyprowadź przewód zasilający, załóż wkładkę ochronną (E) a następnie załóż zaślepkę (B).




3. Połącz przewód zasilający a następnie przyklej oprawę (A) do powierzchni sufitu.




4. Nałóż warstwę gipsu na profil i sufit, a nastepnie pomaluj powierzchnię.




5. Ostrym narzędziem przesuń pomiędzy profilem, a osłoną wzdłuż całej oprawy (po obu stronach wkładki) odcinając warstwę gipsu i farby od wkładki ochronnej.




6. Załóż osłone docelową (C) w miejsce wkładki ochronnej (E).





Parts needed to mount the KOZUS-50 extrusion



Extrusion (A)

End cap (B)

Cover (C)

LED strip (D)

Protective insert (E)

Tools needed for mounting:


- mounting glue

The TECH-50 PROTECTIVE INSERT ensures that the profile slot remains wide enough for the snap-in cover (its use is NECESSARY during mounting and finishing works).


WARNING! All LED strips should be connected to a 12 V or 24 V power supply.

IMPORTANT: The mounting instructions present the basic form of assembly. More methods and related accessories can be found


1. Drill a hole in the extrusion for the power cable.




2. Mount the LED strip (D) in the extrusion, lead out the power cable, insert the protective insert (E) and then insert the end cap (B).




3. Connect the power cable and attach the fixture (A) to the ceiling surface with glue.



4. Apply a layer of plaster to the extrusion and ceiling, and then paint the surface to finish.



5. Slide a sharp tool between the extrusion and the cover (on both sides of the protective insert) to cut off the layer of plaster and paint from the protective insert.



6. Insert the cover (C) in place of protective insert (E).

