



1.1 Profil TEPIKO
1.2 Wkładka ochronna
(Ref. 18046)
2. Profil PIKO-ZM (Ref. C1168)
3. Zaślepka do PIKO-ZM*
4. Zaślepka do TEPIKO*
5. Osłona*
6. Taśma LED*
7. Zatrzask*
8. Zawieszka*
9. Linka stalowa*
10. Zawieszka sufitowa*
11. Dławnica*
12. Zasilacz (12 V / 24 V)*

*Pełen wybór akcesoriów i elektroniki dostępny jest na stronie www.KlusDesign.pl

UWAGA! Wszystkie taśmy LED powinny być podłączone do zasilacza 12 V lub 24 V.

WAŻNE: Instrukcja nie pokazuje wszystkich mozliwości montażu. Dodatkowe akcesoria powiązane z produktem wraz z instrukcjami montażu dostępne są na stronie Rysunki profili i akcesoriów w instrukcji są uproszczone i tylko w przybliżeniu oddają rzeczywiste kształty.

Ia




Wyjmij wkładkę ochronną (1.2) z profilu TEPIKO (1.1).

Wywierć otwór na przewód zasilający.

Zamontuj dławnicę (11) w nawierconym otworze.


IIa



Wyprowadź przewód zasilający zasilacza (12) przez nawiercony wcześniej otwór. Wprowadź końcowy, krótki odcinek przewodu w kanał w głębi profilu i włóż ponownie wkładkę ochronną.

Zamontuj zaślepkę (4).


IIIa



Nałóż obficie klej na wskazane na rysunku ścianki profilu.


Wklej profil we wpust.

IVa




Nałóż klej pod taśmę typu TUFF-TAPE ("taśma amerykańska").

Va



Przyklej taśmę typu TUFF-TAPE na styku skrzydełek profilu i płyty kartonowo-gipsowej.
Nie zakrywaj taśmą wkładki ochronnej.


VIa



Nałóż gładź gipsową.
Wkładka ochronna zabezpieczy wnętrze profilu przed zabrudzeniem.


Wyrównaj powierzchnię.

VIIa




Wyszlifuj powierzchnię papierem ściernym.

VIIIa




Zagruntuj i pomaluj powierzcnię.

IXa




Delikatnie wciśnij palcem powierzchnię zaschniętej farby na długości wkładki ochronnej, aby uwydatnić krawędzie profilu.

Xa




Przetnij warstwy farby i gładzi na styku aluminiowej krawędzi profilu i wkładki ochronnej.

XIa




Delikatnie usuń wkładkę ochronną.

XIIa




Wyjmij przewód zasilający z wewnętrznego kanału profilu.

Ib



Nawierć otwór w profilu PIKO-ZM (2) współosiowo z otworem w listwie montażowej TEPIKO (część Ia).

IIb




Wprowadź zatrzaski TEKNIK (7) oraz zawieszkę FI-10-W (8) w zewnętrzny kanał profilu (zamek mały).

Zalecamy:

- 4 zatrzaski na 1 m profilu,
- 9 zatrzasków na 2 m profilu,
- 14 zatrzasków na 3 m profilu


Przeprowadź przewód zasilający przez nawiercony wcześniej otwór. Wklej taśmę LED. Zamontuj osłonę (5).

IIIb



Zamontuj zaślepki (3).

Ic




Zamontuj zawieszkę sufitową (10) (Więcej informacji na stronie www.KlusDesign.pl).

Połącz przewód zasilający z przewodem oprawy PIKO-ZM. Taśma LED muszą być podłączona do zasilacza 12 V lub 24 V.


Wepnij oprawę PIKO-ZM w przygotowany wcześniej wpust.

IIc



Zawieszkę Fi-10-W (8) zablokuj w wyznaczonej pozycji, dokręcając jej głowicę do profilu.

Zamontuj linkę (9) w zawieszkach. Zablokuj ją dokrecając dociski w głowicach kluczem imbusowym.




1.1 TEPIKO extrusion
1.2 Protective insert
(Ref. 18046)
2. PIKO-ZM extrusion (Ref. C1168)
3. End cap for PIKO-ZM*
4. End cap for TEPIKO*
5. Cover*
6. LED strip*
7. Clip*
8. Fastener*
9. Wire*
10. Ceiling fastener*
11. Gland*
12. Power supply (12 V / 24 V)*

*The selection of electronics and types of accesories available on www.KlusDesign.eu

NOTE! All LED strips must be connected to a 12 V or 24 V power supply.

IMPORTANT: The manual does not present all methods of montage. Other related accessories with instructions of their mounting procedures available at Drawings of extrusions and accessories in this manual are simplified and only approximately represent the real shapes.

Ia




Remove protective insert (1.2) form TEPIKO extrusion (1.1).

Drill the hole for the power supply cable.

Mount the gland (11) on the pre-drilled hole.


IIa



Lead the wire from the power supply (12) through the pre-drilled hole. Put the short end section of the cable into the groove inside the extrusion and put the insert back.


Mount the end cap (4).

IIIa




Place mounting adhesive on the backside of the flanges of the extrusion as shown in the drawing.

IVa




Apply the glue for the TUFF-TAPE.

Va



Apply the TUFF-TAPE where the extrusions wings and drywall panel meet.


VIa



Apply the drywall mud.
The protective insert won't allow the dirt inside.


Even out the surface.

VIIa




Smooth out the surface with a sand paper.

VIIIa




Prime and paint the surface.

IXa




Gently push the dry layer of paint with a finger, on the length of the protective insert, in order to highlight the edges of the extrusion.

Xa




Cut the layers of paint and gypsum with a knife, where the aluminium egdes of extrusion meet the protective insert.

XIa




Gently remove the protective insert.

XIIa




Release the power cable from the inside of the extrusion.

Ib



Drill the hole in the PIKO-ZM extrusion (2) along the same axis as the hole in the TEPIKO mounting track.

IIb




Insert the TEKNIK clips (7), and the FI-10-W fastener (8) into the outer groove of the extrusion. (small lock)

We recommend:

- 4 clips per 1 m / 3.3 ft of the extrusion,
- 9 clips per 2 m / 6.6 ft of the extrusion,
- 14 clips per 3 m / 9.9 ft of the extrusion,


Mount the LED strip. Lead the wire through a pre-drilled hole in the extrusion. Mount the cover (5).

IIIb



Insert the end caps (3).

Ic




Install the ceiling fastener (10) (More information on www.KlusDesign.eu).

Connect the lead wire from the fixture with the power cable.
All LED's must be connected to the 12 V or 24 V power supply

Click the PIKO-ZM fixture into the pre-made groove.

IIc



Lock the FI-10-W fastener (8) in the designated position, by screwing its head to the extrusion.

Mount the wire (9) in the fasteners. Lock it by screwing the pressure screws in the heads with an allen wrench.